

Vejledning til ændring af WIFI kanal på Pace Modem

Gå ind på <http://ibox>

Bemærk at du skal have forbindelse til dit pace modem, enten via WIFI eller kabel.

Klik på WIFI

The screenshot shows the Pace Modem configuration interface. At the top left is the TELE-POST logo. Below it are tabs for 'End User' and 'Administrator', and a 'Home Center >>' link. A left sidebar contains three main sections: 'BOX' with links for 'Services Status', 'Applications', 'Router', and 'WiFi' (highlighted with a red arrow); 'HOME NETWORK' with 'Connected Equipments' and 'Call History'; and 'ADMINISTRATION' with 'Management' and 'Troubleshooting'. The main content area features a welcome message: 'Welcome to your configuration interface'. Below this is a paragraph: 'The Box is configured to deliver the very best in terms of both performance and security. You can also connect various accessories to the Box - so they can be shared by multiple computers and also to give them Internet access.' There are three icons representing different services. Below the icons are three columns: 'Box' with a modem icon and a list of service status options; 'Home Network' with icons for a printer, scanner, and camera; and 'Support' with a headset icon and a link to 'Box Diagnostics'.

Tryk på Auto ved Select channel:

The screenshot shows the 'Wi-Fi Configuration' page. At the top left is the TELE-POST logo. Below it are tabs for 'End User' and 'Administrator', and a 'Home' link. A left sidebar contains three main sections: 'BOX' with links for 'Services Status', 'Applications', 'Router', and 'WiFi' (highlighted with a red arrow); 'HOME NETWORK' with 'Connected Equipments' and 'Call History'; and 'ADMINISTRATION' with 'Management' and 'Troubleshooting'. The main content area features the title 'Wi-Fi Configuration' and a paragraph: 'This page enables you to configure your wireless network parameters.' Below this is a section for 'General Wi-Fi parameters' with the following settings: 'Wifi State: Disabled [Enabled]' (with a red arrow pointing to the 'Enabled' button), 'Select mode: Auto' (dropdown menu), and 'Select channel: Auto' (dropdown menu). Below this is a section for 'SSID 1 Wi-Fi parameters' with a paragraph: 'The Wi-Fi connection uses SSID 1 as the default. You can change the parameters of this network to meet your needs.'

Vælg en tilfældig kanal, her er så valgt kanal 3. De typisk anvendte kanaler er 6 og 11, så prøv at vælge en anden kanal end disse. Tryk derefter ok nede i bunden.

General Wi-Fi parameters

Wifi State: Disabled Enabled

Select mode: Auto Select channel: 3

SSID 1 Wi-Fi parameters

The Wi-Fi connection uses SSID 1 as the default. You can change the parameters of this network to meet your needs.

SSID (name of WiFi network)

Name of SSID: Mask SSID:

WPS

Enable WPS
WPS Method: Button

Security

None WEP WPA WPA2 WPAWPA2

Select option: AES
Password:

Advanced Configuration

DTIM Period: 1

MAC filtering - list of registered terminals

Status of filtering: Disabled Enabled

Terminal	MAC Address	Actions
<input type="text"/>	<input type="text"/>	Add

OK

Når dette er gjort, kan det være nødvendigt at slukke og tænde sit modem igen. Man kan efter den er tændt og oprettet forbindelse gå ind i <http://ibox> og se om kanal er ændret under WIFI.